


- NOTES:
- ⚠ NOTE 1 WHEN SP40S IS IN ALARM CONTACTS WILL OPEN TO DISABLE FACP
 - ⚠ NOTE 2 10K EOLR
 - ⚠ NOTE 3 2.2K EOLR
 - ⚠ NOTE 4 EOLR IS DEPENDENT OF THE FACP
 - ⚠ NOTE 5 INPUT IS A CONTACT CLOSURE

SCALE: N/A	ORIG. BY: JB	
AUTOCAD FILE NAME: M-0001-07	DATE: 3/07	
WHEELLOCK, INC. DISCLAIMER This document provides information on an as-is basis to assist users and their technical advisors in selecting elements for notification circuits and/or facility communication systems. Wheelock, Inc. does not hold itself out as providing design or engineering services. Users are solely responsible for their own selection and use of products, and Wheelock, Inc. shall have no liability therefor. ALL WARRANTIES INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED.		 273 BRANCHPORT AVENUE LONGBRANCH, NJ 07740 (800) 631-2148